

# GXDB Remote

## Basic Operation Guide

Check Battery Installation information in owner's manual first.

For controlling other devices see the Remote Control Programming sheet.

**TV** Allow the remote to function with your Sanyo HDTV.

**Power On/Off** Power On or power Off your HDTV.

**MENU** Displays the on-screen menu.

**OK/ENTER** Move the cursor in the menu screens. Select highlighted menu options.

**RESET** Press twice to restore your HDTV to its original factory settings.

**VOL** Set the loudness level of the audio output.  
+ to increase  
- to decrease

**MUTE** Sets the volume level to 0. Restores the volume to the previous level before muting.

**INPUT** Switch from one Video input source to another. *NOTE: Hold for three seconds to open the Input List menu.*

**AUDIO** Selects the desired audio mode (when available).

**PIX SHAPE** Choose between available aspect ratio options Pix1 thru Pix7 and Pix-Auto (for digital channels) to enable or disable image stretch.

**PICTURE** Cycle through the predetermined picture modes.

**SOUND** Cycle through the predetermined sound modes.

**INFO** Display channel banner information.

**EXIT** Exit the the current on-screen menu and return to normal TV viewing.

**XACTI MENU** W T Activate Xacti functions when Xacti camera connected via HDMI.

**RECALL** Switch back and forth between the last two selected channels.

**CH** Scan through the channels in the HDTV's memory database.  
▲ for a higher channel  
▼ for a lower channel

**0 through 9** Tune to a channel directly. Ex: Press 0 then 6 for channel 6. *NOTE: Press and hold the 1 key to activate the first of three digits for channels 100 and higher.*

**USB** Switch directly to the USB input.

**CC CAPTION** Enable / disable digital caption options CC1-CC6 (digital) or CC1-CC4 (analog).

**SLEEP** Displays SLEEP timer. Pressing "0" key sets the Off Timer.

**ON TIMER** Displays the Switch On Time banner.

**HELP** Displays the On-screen Help menu with common problems and solutions.

**SANYO**  
GXDB  
1-800-877-5032

For assistance call the toll free number 1.800.877.5032 or visit our website at [www.sanyoctv.com](http://www.sanyoctv.com)

