

### PLC-XP100 IR Command List

Transmission format of LCD projector operation key

: NEC Format (single command / command pipelining mode)

Transmission format of PC mouse operation button (mouse cursor button) / L / R key

: Interlink Mouse Code Format (Includes 3 bit of ID)

Format for the transmission of OSD Laser operation button (mouse cursor button)

: Interlink OSD Mouse Code Format (Includes 3 bit of ID)

Custom Code + Custom Code

: 8 patterns as below

33h+00h(Default),33h+11h(code2),33h+22h(code3),33h+33h(code4),

33h+44h(code5),33h+55h(code6),33h+66h(code7),33h+77h(code8)

Key No.	Data Code (HEX)	Function
1	*1	L-CLICK <input type="checkbox"/> Back-side Click Trigger Key
2	11	ON
3	10	STAND-BY
4	38	INPUT1
5	39	INPUT2
6	06	INPUT3
7	89	AUTO PC
8	43	FREEZE
9	08	NETWORK
10	8C	CURSOR UP
11	1E	CURSOR LEFT
12	1D	CURSOR RIGHT
13	8D	CURSOR DOWN
14	1C	MENU
15	84	POINTER
16	*1	R-CLICK
17	8A	P-TIMER (Number 1)
18	88	D.ZOOM (Number 2)
19	82	SCREEN (Number 3)
20	47	ZOOM + (Number 4)
21	4A	FOCUS + (Number 5)
22	40	LENS SHIFT (Number 6)
23	46	ZOOM - (Number 7)
24	4B	FOCUS - (Number 8)
25	5B	KEYSTONE (Number 9)
26	16	INFO
27	1A	FILTER (Number 0)
28	8B	NO SHOW
0B1	OF / *1	SELECT / Mouse Cursor button

\*1... Transmit code for Mouse