

Please READ and REMOVE this guide before operating your HDTV



**HD** QUALITY PICTURE  
High Definition

# QUICK 'N EASY Setup Guide

Simple step by step procedures for correct HD hookups and initial setup process.

## 1 Attach the Stand Base to the HDTV.


For additional information, consult your HDTV's owner's manual.

## 2 Hookup your Audio/Video equipment to the HDTV.

Use Component or HDMI connections, and a High Definition source for the best picture possible. Your AV equipment Output Jacks must be connected to the HDTV's Input Jacks. Always match the color of the jacks and connectors.



Video Game System



Part No. 1JC6P1P0391--

## EXPERIENCE THE BEST IMAGE QUALITY ON YOUR HDTV

CONNECTION TYPE	CABLE/CONNECTOR	IMAGE QUALITY
	Antenna or Digital Cable	★★★ BEST
		★★★ BEST
		★★★ BETTER
		★★★ GOOD


For the best HD experience, be sure to use HD devices and/or HD off-air signals transmitting HD content.

## 3 Hook up your antenna or direct Cable service.


An indoor antenna should be placed at least 3 ft away from the HDTV.



Best  
**HDMI** ★★★



Blu-ray / HD DVD player




HD SAT/Cable  
(or other digital device)


See reverse side to continue your HDTV's initial setup!



**4** **Connect the AC cord to the HDTV and to power outlet.**  
Use the **POWER** key to turn on your HDTV.





**5** **Use the on-screen menu to select your HDTV's location.**  
Use the **CURSOR** ▲ ▼ keys to highlight the desired option and press the **ENTER** key.  
**NOTE:** Selecting Home mode will qualify as an Energy Star rating.



**6** **Perform a Signal search.**

Use the **CURSOR** ▲ ▼ keys to highlight the **Signal Search** option and press the **ENTER** key.


Please allow the HDTV a few minutes to complete the process.



**7** **Finalize the completed Setup process.**

Use the **CURSOR** ▲ ▼ keys to highlight the **Finish Setup** option and press the **ENTER** key.

You can now watch and enjoy TV programming on your HDTV!



**8** **Choose the correct Input source**

Use the **INPUT** key on your remote control to select from the available Input sources on your HDTV.

**NOTE:** If you receive Satellite or Cable service through a set top box, tune to the correct input on your HDTV and use the receiver and its remote for channel viewing.



**Si necesita ayuda en ESPAÑOL, marque al 1-800-877-5032 y un asesor estará dispuesto a ofrecerle ayuda con cualquiera de sus dudas.**

Use the following codes to program your cable or satellite provider's remote control to work with your new HDTV.

Direct TV	10154, 960 (to activate INPUT feature)
Dish Network	590, 683, 589, 542, 652
Comcast	10154
Cox	0154, 0088
Verizon	0181, 0826, 0920
ATT	1045, 1062, 1095, 1380

**NOTE:** If these do not work, refer to your Cable or Satellite manual.

**SANYO**

Sanyo Manufacturing Corp.  
3333 Sanyo Road, Forrest City, AR 72335

**Need help?**



Visit our website  
[www.sanyoctv.com](http://www.sanyoctv.com)



Call toll free  
1.800.877.5032



One of our Service associates will be glad to assist you!